


Issue 363

PS

February
1983

THE PREVENTIVE MAINTENANCE MONTHLY

Be a
SWEETHEART...
Let somebody
else read
this issue!



The time has come
to tell it True
And lay it on
the Line --
Your PM's Great,
so why don't you
Please be our
Valentine?!

Windy

Connie

Half-Wast

Bonnie

Macon

MURPHY
ANDERSON

Published by the Department of the Army for the information of all soldiers assigned to combat and combat support units, and all soldiers with organizational maintenance and supply duties. Within limits of availability, older issues may be obtained direct from Editor, PS Magazine, c/o US Army Materiel Readiness Support Activity, Lexington, KY 40511.

ISSUE NO. 363 FEBRUARY 1983

GROUND MOBILITY

Tire Pressure	4	Wheel Lift	11
M915-Series Trucks	5	¼-Ton Jacks	12
Truck Frame Rivets	6	¾-Ton Trailers	12
Windshield Washer	7	Oil Filters	13
Bearings & Brakes	8	5-Ton Air Cleaner	13
Seat Cushion	9	M880 Tail Lamp	13
Multifuel Fuel Filter	10	Battery Hookups	29

FIREPOWER

Air Cleaner Tips	14	M88A1 Lifting Sling	20
M60A3 Rangefinder	17	M30 Mortar	21
M548 Air Brakes	18	TOW Tips	22
M110/M578 Roadwheels	18	TOW/Dragon Targets	23
M102 Recoil Mechanism	19	M60 MG	24
T130/T130E1 Track	19	M240 MG	25
		Small Arms PMCS	26
		M3A1 MG	26
		M16A1 Rifle	27

AIR MOBILITY

Sight Gage Puller	37	Aux Power Unit	41
Maint Platforms	38	OH-58A/C Main Rotor	42
Black Hawk Bearings	40	OH-58A/C Oil Cooler	42
Oil Level Check	41	U-21, U-8	43
		Aviation Messages	43

TROOP SUPPORT

Operator Training	1	D7E/F Cat	50
New Pubs	28	JD 410 Backhoe	50
High-Security Padlocks	44	H100C Scoop Loader	51
Mattress/Bag Repair	48	Equipment Codes	52
Jumper Cable Clamps	48	Antifreeze Stencil	54
MKT-75 Kitchen	49	Supply Hotline	54
Bridge Boat Battery	49	SF 368	55
		DA Pam 310-1	56
		DA Form 1352	56
		Generator Pubs	57

COMMUNICATIONS

Commo Cables	34	MK-1823, -1885 Kits	63
AN/UGC-74A (V) 3	58	AN/PVS-5 Goggles	64
TD-660 Multiplexer	62	O-Rings	64

PS wants your ideas and contributions, and is glad to answer your questions. Name and address are kept in confidence. Just write to:

MSG Half-Mast
PS Magazine
Lexington, KY
40511

Use of funds for printing of this publication has been approved by Headquarters, Department of the Army, 10 September 1982 in accordance with AR 310-1.

DISTRIBUTION: In accordance with requirements submitted on DA Form 1275. Private subscriptions: Order from US Govt Printing Office, Suit of Documents, Washington, DC 20402, \$24 per year to US and APO; \$30 to foreign address.

PS Magazine ISSN 0475-2953 is published monthly by the Department of the Army, Washington, DC. Second Class Postage is paid at the Lexington, KY post office and at additional mailing offices.

Postmaster: Send address changes to: Cdr. US Army Pubs Ctr, 2800 Eastern Blvd, Baltimore, MD 21220.

Making Good Operators...

A Formula




IT'S NOT AS EASY AS 1+1=2!

BUT THERE IS A FORMULA FOR MAKING GOOD EQUIPMENT OPERATORS...

You take some time, add a heap of patience and know-how, train, then train some more, and you get a good operator.

You and your outfit supply the time and patience, but the Army has some material to add to your experience and know-how.

for SUCCESS



BEFORE YOU SET UP A TRAINING PROGRAM...

... LOOK OVER THIS LIST OF PUBS FOR ONES THAT SUIT YOUR NEEDS...

58-1 w/C1

190-5 w/C2

385-10

385-40

385-55

600-55

310-8

611-125 w/C1

20-22

21-6

21-17

21-60

21-305 w/C2

55-30 w/C1

Army Regulations

Management, Acquisition and Use of Administrative Use Motor Vehicles. Chap 10 will help you if you have admin-use (non-tactical) vehicles.

Motor Vehicle Traffic Supervision

Army Safety Program

Accident Reporting and Records

Prevention of Motor Vehicle Accidents

Motor Vehicle Driver-Selection, Testing and Licensing

DA Pamphlets

Index of Army Personnel Tests and Measures

Test Procedures for Licensing Drivers of Army Vehicles

Field Manuals

Vehicle Recovery Operations

How to Prepare and Conduct Military Training

Driver Selection, Training and Supervision—Track Combat Vehicles

Visual Signals

Manual for the Wheeled Vehicle Driver

Army Motor Transport Units and Operations (Chap 9 replaced TM 21-300)

Technical Bulletins

- 9-2320-218-10-1 Safe Operation of Truck, Utility, ¼-Ton, 4 X 4, M151-Series
- 600-1 w/C2 Procedures for Selecting, Training, Testing and Qualifying Operators of Equipment/Systems (except selected watercraft and aircraft) managed/supported by TSARCOM. Covers gear like generators, compressors, water purification sets, pumps, truck-mounted mine detectors, MUST's, fire trucks
- 600-2 Procedures for selecting, training, testing, qualifying and licensing operators of construction, MHE, AVLB equipment
- 9-1200-209-10 Multiple Integrated Laser Engagement System (MILES)

Technical Manuals

- 9-8000 Principles of Motor Vehicles
- 21-306 Manual for the Track Combat Vehicle Driver
- 38-600 Administrative-Use Vehicle Management
- 38-750 The Army Maintenance Management System (TAMMS)

Depending on your unit mission and equipment, other pubs should be added or used.

FOR EXAMPLE...

YOU MAY WANT YOUR OPERATORS TO KNOW ABOUT THESE...

- FM 31-35 Jungle Operations
- FM 31-71 Northern Operations
- FM 90-3 Desert Operations
- TB 43-0239 Maintenance in the Desert
- FM 90-6 Mountain Operations
- FM 90-13 River Crossing Operations

DA Pam 310-1, Consolidated Index of Army Pubs and Forms (fiche), will tell you what pubs are available on your gear or mission.

Maybe your operators respond better to films or training aids? DA Pam 108-1, Index of Army Motion Pictures and Related Audio-Visual Aids, and Extension Training Material Catalogs in the DA Pam 350-series list current films, TEC lessons, graphic training aids and more.

'COURSE, ALL YOUR TRAINING EFFORTS BUILD ON THE OPERATOR'S MANUAL ON THE GEAR!

MAKE SURE YOUR OPERATORS ALL HAVE AN UP-TO-DATE COPY...

AND USE IT!

YOU'LL FIND SOMETHING ON ALMOST EVERY TYPE OF GEAR OR OPERATION!

FOR EXAMPLE...

- TF 9-3106
- TF 9-3107
- TF 9-3359
- TF 9-3381, -3382, -3383, -3384
- TF 9-6099
- MF 17-5934
- MF 20-5152
- TF 55-3707
- TF 55-4167, -4168
- TF 55-4247
- TF 55-4277

- TVT 55-102
- TVT 55-103, -104, -105, -106, -107

- 020-171-5802F
- 945-171-0100F
- 945-171-0101F

C 11-8-1

C 11-8-2

C 5-4-29-series

Training Films

- DC Motors and Generators
- AC Motors and Generators
- Howitzers M108, M109
- Recovery Vehicle, M88

Safe Operation of the Gama Goat

Goer

National Driver's Test

Operation of M151-Series ¼-Ton Trucks

Safe Military Vehicle Operator

Truck, ¼-Ton M151A2

Driving the Tractor and Semitrailer

TV Videotapes

Traction Aids and the Winch

M911 (C-HET)

Training Extension Courses (TEC)

Combat Driving

Varied Terrain Driving

Reduced Traction and Hazards

Graphic Training Aids

Operating PU-617/M, PU-628/G, PU-625/G

Operating PU-618/M and PU-619/M

Operation of Rough Terrain Forklift Trucks

Your local safety office, driver's testing station or the MP's can tell you about any locally required training, like a defensive driver's course.

But other than the 2 training films on the M151-series, the headshed leaves training requirements up to your SOP.

So it's pretty much up to you to make sure your operators are trained and licensed and able to handle the equipment your unit's mission demands.

Hammer Shows Up "LAZY" Tires

YES, PVT. BASHEM... THE HAMMER TEST IS GREAT FOR DETECTING AN UNDERINFLATED DUAL...

...BUT A BALL-PEEN HAMMER IS ENOUGH FOR EVEN THE BIGGEST RIG!

WHEW! THANKS, BONNIE...

HE MIGHTA KILLED ME!

If the PMCS for your truck or trailer is up to date, you find that you're no longer required to gage tire pressure as part of the "before operation" inspection. "Weekly" is enough.

But you do eyeball the tires closely "before operation" for cuts and other damage—and for flats.

Trouble is, how do you spot an underinflated tire in a set of duals when its mate is carrying the load? A soft tire may stand up straight 'n' tall

Underinflated? You can't tell just by looking!

when it's alongside a fully inflated tire—especially under a light load.

And if you're like a lot of drivers, you pull your "before operation" PMCS before the vehicle's dispatched to you—when it's empty—and that's the end of it. The load on that good tire is nothing compared

Going to carry a HEAVY load?...



to what it'll be when you take on a few tons of cargo—or when you roll a bulldozer or tank onto your lowbed semitrailer.

M915-Series...

Tires Differ Between Models

YUP! I'M AN OFF-THE-ROAD TIRE... SO WOT?

YER NOT AUTHORIZED...

GET LOST!

You can quit looking for off-the-road tires for your M915-series trucks—they're not authorized.

M915 truck-tractors use 10.00x20 size tires with a highway tread de-

For M915 only

sign. Use NSN 2610-00-060-9960 to order this tire.

Front-wheel-drive M916 thru M920 trucks take a larger tire—11.00x24—designed for both normal highway operation and limited use on

For M916 thru M920

secondary roads. NSN 2610-00-489-8040 gets this tire. It replaces NSN 2610-00-294-9483, a straight off-the-road tire.

Give every tire a good whack!



inflated tire goofing off, the other tire's not long for this world!

When your eyes can't spot a soft tire, a hammer can. As you do your "before operation" walk-around, give every tire a good whack with your hammer. "Pong" is good—your hammer will bounce smartly off a fully inflated tire.

A DULL, MUSHY "THUNK" MEANS YOU'D BETTER DOUBLECHECK WITH YOUR TIRE GAGE--AND INFLATE AS NEEDED!

Loose Frame Rivets? NMC!

HMMM... SOMETHIN'
RATTLING 'N' BANGING
UNDER THERE! I'LL HAFTA
CHECK YER FRAME
RIVETS ONE O'
THESE DAYS!



Just one loose rivet in the frame causes an NMC (not mission capable) rating for your truck when you're pulling your PMCS.

That's the word in TM 9-2320-209-10-2, TM 9-2320-211-10-2 and TM 9-2320-260-10-2. "Loose" is intended to apply to "bolts or rivets" as well as to "side rails" and "crossmembers".

So you've got to sharpen your eyes when you're making this monthly check of the UNDERBODY, FRAME. There're a lot of rivets under there—and you need to check every one of 'em.

A loose rivet is big trouble in the making—like a small leak in a dam that keeps getting bigger. A loose rivet allows a little shifting of the frame members at that point. This adds to the strain on the other rivets. They'll loosen or even break. Your frame will come apart!

When you find a loose rivet, report it—pronto. Your DS will take care of the repair.

Look, Feel


One sign of a loose rivet is shiny metal on the frame around the rivet head. This means the rivet is moving and rubbing the frame.



The rivet's really a sloppy fit if you can wiggle it with your fingers.



Rust around the rivet head is a clue, too. If your truck sits still for a long time, the "shiny metal" around a loose rivet becomes rusted metal. You



'n' Whack

may not be able to wiggle the rivet because of rust buildup under the rivet head. But you can check with oil and a hammer...


—Squirt some light oil around the rivet head.



—Let the oil soak in.

—Wipe the oil off with a rag.

—Give the rivet a good whack with a small hammer.



—Watch for oil to be squeezed out from under the rivet head.

If oil does show up, that rivet is probably loose. Report it!

YOU BETTER CHECK
'EM RIGHT NOW!

MY CROSSMEMBERS
ARE 'BOUT TO FALL
OFF--
AND THAT'LL BE ALL
SHE WROTE!

Windshield Washer: Act 2

There's been a lot of interest in the windshield washer kit mentioned in PS 355. But some people wonder why the kit's coded for Organizational Maintenance in the parts manual while being listed for DS in the MAC.

Here's the updated story:

The windshield washer installation kit, NSN 2540-00-279-8180, now in TM 9-2320-209-34P, will show up in the -20P with the same SMR Code—PAOZZ.

The MAC in the -20-1 TM will be changed to show installation of the kit as an Org Maint job.

The same info will show up in TM 9-2320-211-20-1 and -20P and in TM 9-2320-260-20-1 and -20P for the 5-ton trucks.

Instructions for installation come with the kit.

2½- and 5-Ton Trucks...

Cork Protects Bearings & Brakes


REMEMBER THE ALAMO!

REMEMBER PEARL HARBOR!

REMEMBER THE CORK INSERT!

Right, that itty-bitty hunk o' cork that helps keep oil out of the rear wheel bearings on your 2½-ton and 5-ton trucks. You sure don't want oil washing the grease out of those bearings. They need grease—they'll burn up without it!

THESE PICTURES SHOW THE SET UP FOR 2½-TON TRUCKS... BUT THE CORK INSERT GOES IN THE SAME WAY ON 5-TON TRUCKS!



And you don't want oil in your brake drum. Oil on brake linings means no brakes! This can happen when the cork insert's missing and oil gets by a faulty inner seal.

Oil in the axle housing is free to travel out the end of the axle housing spindle. The outer seal blocks this oil from getting into the hub—except where the spindle keyway offers a handy channel under the outer bearing.

This's where the cork insert stars. It's jammed in the keyway under the bearing. It's a plug. It stops oil from getting into the hub.




IT'S A TRUCK'S BEST FRIEND!

CORK INSERT?

Yup!

Note for your -20 TM

You won't find this cork insert mentioned in your -20 TM—TM 9-2320-209-20-3-2, TM 9-2320-211-20-3-2 or TM 9-2320-260-20-3-2. It should be shown in Section III, Rear Wheel Assembly, along with the outer bearing, outer seal, adjusting nut, lockwasher and locknut.



The cork insert is jammed under the bearing by the seal keyway tang when pressure is applied by the nut

YOU WILL FIND THE CORK INSERT LISTED AS A REPAIR PART IN 2 OF THE 3 -20P TMs...

Item 7, Fig 110, TM 9-2320-209-20P, Cork, wheel bearing lock keyway, NSN 5330-00-348-8365.
Item 3, Fig 13-2, TM 9-2320-260-20P, Insert, keyway oil seal, PN 8758266.

Or you can make a lot of inserts from a cork sheet, NSN 5330-00-350-9099.

2½- & 5-Ton Seats

The deuce-and-a-half's companion seat back cushion shown in Fig 162 of TM 9-2320-209-20P has been dropped.

Order the substitute, NSN 2540-00-737-3311. This is the same cushion that's used on the 5-ton trucks.

There are 2 interchangeable seat assemblies that you can use on any of these trucks, NSN 2540-00-407-2611 and NSN 2540-00-737-3307. They are both listed in TM 9-2320-209-20P.



HEY! HE'S GOT MY COMPANION SEAT!


NO! IT'S MINE!

FITS YA BOTH!


2½-Ton & 5-Ton Trucks...

Multifuel Fuel Filter Facts

The primary fuel filter on all 2½-ton multifuel engine trucks and on most 5-ton multifuel engine trucks is the same.



This is the non-scrap-er-type fuel filter under the left front fender of later model 5-ton multifuels covered by the TM 9-2320-211-series. But, there's



nothing about the filter in your TM 9-2320-211-20P.

Fig 34 in TM 9-2320-209-20P for multifuel deuce-and-a-halves is confusing. The "ghosting" of some parts leads you to think that you won't get 'em with the filter assembly.

SO KEEP THIS INFO WITH YOUR -20P UNTIL THE TM'S ARE UP-DATED!


Complete assembly, NSN 2910-00-795-1783

Nut, NSN 2910-00-791-3352

Gasket set, NSN 5330-00-678-3298

Element, NSN 2910-00-790-2300

Drain cock, NSN 4820-00-752-9040



SOME PEOPLE KNOW IT, SOME DON'T...

TELL 'EM, BONNIE!


Give Seals a Lift

GOOD GRIEF! WHAT HAPPENED?

ER... MY MECH SEZ ONLY WEAKLINGS USE A WHEEL LIFT, BONNIE!


Are you tired of bunged-up axle threads, leaky axle seals and wheel bearings that don't last?

Bunged-up threads?



All these things can happen—at the same time—when you don't get everything lined up just right when you are putting the wheel and hub assembly back on.


The wheel lift picks up the wheel and hub assembly which makes it



easier to line everything up. Getting everything straight heads off damage to the threads, bearings and seals.

Your wheel lift works best on a smooth, flat surface. When you use it in the field, use a piece of plywood under it.

Get a buddy to help when you install the wheels. An extra pair of eyes can make sure everything is lined up just right.



There's an easy way to head off damage and save your back, too. It's your wheel lift truck, NSN 4910-00-554-5983 in the No. 1 Common shop set.

Brittle Won't Do

EMPTY!

THE VALENTINE'S LOST!
I WONDER IF SP4 JONES CHECKED
TH' SEAL ON THIS ENVELOPE?

NOT LIKELY, CONNIE--
HE NEVER CHECKS TH'
SEALS ON MY AIR
CLEANER DOORS!


Ever try to seal an envelope when the glue has dried out?

You won't have much more luck protecting your tank's engine against dirt and dust if the air cleaner door seal is brittle.



Dirt in air cleaner box

Next time you have the air cleaner element out for service, check the door seal. If it's brittle or has tears, cuts or gouges, replace it. It's worthless against dust and dirt.



Seal for top-loader

NSN 5330-00-259-0469 gets the seal for the aluminum top-loader door; NSN 5330-01-030-6807 is the seal for the steel top-loader door.

Do

If you don't know aluminum from steel, don't try to substitute one seal for the other. The seals are different sizes.

Use the magnetic retrieving tool, NSN 5120-00-545-4268, from the No. 1 or No. 2 Common tool set to find out what your tank's air cleaner doors are made of.

THIS MAGNET
WILL STICK TO
STEEL -- BUT
NOT TO ALUMINUM!

CAREFUL! I'M
TICKLISH!

If you've got a side-loading air cleaner, the seal you need is NSN 2940-00-411-2060.



Side loader seal

Use the same adhesive on all 3 seals. Get a 2½-oz can with NSN 8040-00-152-0063 or a 6-oz can with NSN 8040-00-152-0067.

To keep the seals from sticking to the air cleaner housing, coat them with a thin film of silicone grease. NSN 6850-00-880-7616 gets an 8-oz tube and NSN 6850-00-295-7685 gets a 10-lb can. Never use GAA 'cause it'll ruin the seal.

M48/M60-Series Tanks...

No Mix, No Match

HERE Y'ARE!

OH, NO!

HOLD ONE!

If you're getting ready to replace the door on your tank's top-loading air cleaner, hold one.

You'll cause as much damage to the air cleaner system as you're trying to prevent.


That's right, because the doors are not interchangeable.

Each door is matched to the air



Cam arms...

cleaner box so the cam arms engage the filter element locking tabs to form a tight seal.



...engage locking tabs

When they're not matched, dust and dirt will bypass the filter and KO your engine.

If the door is damaged enough to be replaced, you have to replace the entire air cleaner box assembly.

M48/M60- Series Tanks...

Clean air for your tank's engine is a must. Everybody knows that.

But, there's more to providing that clean air than keeping the filter elements clean.

Air cleaner hoses and clamps must be in ship-shape order, too.

HERE'RE
A FEW
TIPS FOR
YOU
MECHS
AT
Q-SERVICE
TIME...

• When you check air cleaner system hoses for holes or cracks, also check hose alinement. A hose that looks too short may be misalined. That could let dirt in at the connection points.

Check for
holes or
cracks...

...and
doublecheck
clamps!

• Doublecheck the hose connections. Seat clamps or bands right and tighten 'em snug. If a clamp or clamp screw is damaged, replace the clamp. If a finger-type clamp is bad, replace it. The same goes for V-band or flat-band clamps.

• Make sure the air inlet screen and inlet hose are clean. Also test the air flow with a strip of paper while the engine is running.

Air inlet
screen
clean?

16

Ah! Clean Air



When a
Tank Stalls...

Hit the Brakes!

WHAT TH'--
THIS HEAP'S
ROLLING BACKWARD!!

OH, NO!!
STOP IT QUICK!
IT'LL FRY
OUR AIR
CLEANER
SYSTEM!

If your M48A5 or M60-series tank stalls and rolls backward with the transmission in a forward gear, the engine reverses.

The exhaust becomes the air intake and the air intake becomes the exhaust.

So what kind of shape does that leave your air cleaner system in? Bad!

Seals and hoses get baked. Diesel exhaust fumes turn the inside of the air filter element black with carbon. Heat burns holes in the filter element.

Some air cleaner system damage can be repaired, but the filter element must be replaced. It cannot be cleaned and reused.

You can't avoid steep inclines, true. But you can save your air cleaner system lots of damage by hitting the parking brake before the tank begins to roll backward.

Hold the tank with the brakes until you can restart and move under power.

M60A3 Tank...

Laser Rangefinder Filter NSN's

The NSN's for some of the LRF filters are missing from your TM 9-2350-253-10, but not to worry.

HERE'S A
LIST OF THE
MISSING
NSN'S IN
ITEM 13 ON
PAGE B-4!

MAKE A
NOTE UNTIL
THE NEXT
REVISION
OF THE TM
PICKS 'EM
UP...

Filter	NSN
Green laser safe (TTS and M35E1)	1240-01-114-9502
Green laser safe (M105)	1240-01-115-1082
Green laser safe (M36E1)	1240-01-117-3750

If you need the bracket for the filter box, the NSN is 1015-01-077-6058. The washer NSN is 5310-00-982-6580.

'Course, the whole system must be working right for you to get the most out of your tank.

OVERLOOKING
ANY PART OF THE
SYSTEM COULD
MAKE YOUR TANK
CONK OUT ON THE
BATTLEFIELD!



17

M548
Cargo
Carriers...

Inspect Air Brakes Now

WHADDAYAMEAN IT'S
OUTTA CONTROL? DIDJA CHECK
OUT TH' BRAKE AIR COMPRESSOR
LIKE SARGE SAID?



WELL...
ER...
UH...
I...

Inspect all your M548's equipped with air brake kits to see if the air compressor is installed right.

The head and block assembly must be mounted so the air strainer and discharge flange face to the left, looking from the shaft/pulley end of the compressor.

If your compressor looks
like this, it's wrong...

...it should be
installed like so:



Otherwise, there may be interference between the compressor and the accelerator linkage. That could cause a linkage hang-up and temporary loss of control.

Para 3-8 of TB 43-0001-39-4 (Jan 81) has the word on installing the compressor. The TB item is for 2½- and 5-ton multifuel vehicles, but the compressor's the same one used in the M548.


M110/M578 Vehicles...

Roadwheel Arm Lubrication



So how much grease do you put in the roadwheel arms of your vehicle?

The LO doesn't help, for sure. Plus, there're 2 fittings on the arm that are real close together. So what do you do?



Reading
the Pin...

An Indicator of Reserve

Checking the oil index indicator on your M102 towed howitzer's recoil mechanism is pretty simple—if you know which recoil mechanism you've got.

You check the old style M37 by looking at the index pin. If the pin is flush with the face of the control

Pin flush?
OK to fire!



assembly, or doesn't extend 3/16 inch or more, the oil reserve is OK and you can fire the howitzer.

You must add oil before you fire if


the pin extends 3/16 inch or more.

The oil indicator housing on the new style M37A1 has been extended to increase the oil reserve.

Plus, there is a guard over the pin end of the housing.

The red tab inside the guard is the key to reading the pin. You can fire the M37A1-equipped howitzer as

Indicator pin extended
to red tab? Add oil!



long as the indicator pin does not extend to the red tab.

Add oil before firing if the pin extends to or past the red tab.

T130/
T130E1
Track...


A Winning Angle



Everybody plays the angles at one time or another. You need to play one too, every time you connect T130 or T130E1 track.

Your angle is 20 degrees, as shown

This distance
is about 2 inches



20° angle

2 inches
(approx)

pin's flat surfaces match up with the flat surfaces of the track bushings.

Otherwise, the bushings take a beating and wear out long before their time.


Worn bushings make dead shoes and dead shoes can make your vehicle Not Mission Capable (NMC).

Play the angle and come out a winner. You can't lose.

on Pages 3-20 thru 3-22 of TM 9-2300-257-10.


You need that angle so the track

Watch that Sling!



Never use your final drive lifting sling, NSN 4910-01-046-8944, until it has been load-tested by your GS-level maintenance unit.

The welds on some slings have




failed, and people have narrowly escaped injury when the slings broke.

If the sling you use has not been tested by GS-level maintenance, contact your local Logistics Assistance Office or field maintenance technician for details on how to turn it in.

You can tell if your sling has been tested. It'll have a stamp or mark on it indicating the date of test.

Be sure to follow the final drive removal procedures in TM 9-2350-




256-20. In particular, make sure the lifting sling lifts just the final drive.

The sling was designed to lift the final drive, not the vehicle hull. If the drive sags as it's pried loose, it could catch on the hull as it's lifted. That additional weight could cause the sling to fail.

Make sure the final drive doesn't catch on the hull during the removal.

Never stand under or near the sling when the final drive is being lifted.


M30 Mortar Checks




• Loose elevating cap or sleeve in elevation and recoil group.



• Burrs on sight mount knob.




• Paint on lens of M53 sight-unit (and other sightunits). Watch with the spot painting...and remove unwanted spots.



WANNA BEAT THE HEAT WHEN INSPECTORS COME 'ROUND TO CHECK OUT YOUR M30 MORTARS? HERE ARE SOME OF THE MOST COMMON FAULTS THEY WRITE YOU UP FOR...

• Loose or weak shocks that need to be repaired or replaced.



• Too much play in the traversing handle ($\frac{1}{8}$ turn allowed).




Tables 3-1 and 3-2 of TM 9-1015-215-12 clue you on the preventive maintenance you've gotta do to avoid deficiencies.

Successful Mating



Optical Sight

Never lock the optical sight to the traversing unit before it's seated right. That'll knock you out of business by damaging the pins in the electrical connector.




To prevent damage, do this:

Guide the optical sight's hook mount over the traversing unit index plate. Then mate the "key" in the index plate guide flush with the grooves in the optical sight's index plate.

Take care when you're plugging into the missile guidance set. Clean any dirt from the coil cord connector. Dirt won't let the connector make good contact with the J1 connector. A bad contact means the difference between a "hit" and a "miss."

Coil Cord

Go easy on the pins in the coil cord connector. That means make sure you line up the yellow index line on the cord connector with the yellow mating line before you push down on the cord connector. Then snug up the locking nut.



Latch the Hatch!

You M901 drivers better say goodbye to the sky before the gunner fires a missile. Close the driver's and gunner's hatches before traversing the weapon station or launching a missile. If you don't shut the hatch, the revolving turret could knock off a hatch or damage the proximity switch.



TOW/Dragon Target Board




Save a box, save a board.

That's as simple as it can be when you stow your TOW/Dragon system target boards.

Save the box the boards come in, as well as the styrofoam divider that separates the 2 boards.

When you store 1 or both boards, put them in the box with the divider covering the front. That saves expensive damage to the face.

If you don't have the box, put cardboard, canvas or whatever over the face of the boards.




M60 Forearm Fix

Want to save damage to the forearm assembly catch on your M60 machine gun ...and maybe loss of the catch spring?

Do like Page 46 of TM 9-1005-224-10 (Mar 81) tells you.

Use a dummy cartridge or your combination wrench to push in on the spring through the bottom of the forearm. When the spring's depressed, lift the forearm up and off.

When you put the forearm back



on, do it with a slow, steady push. If you snap or slam it on, you can damage the catch.



Spring Guide(line)

Never use the operating rod's spring guide of your M60 machine gun to disassemble the weapon's forearm assembly.



The spring guide gets bent out of shape when you poke it in the forearm assembly to release the spring.

A bent guide causes feeding problems, like sluggish operation.

The bottom line? Use a dummy cartridge, a cleaning rod or the combination wrench that comes with your weapon.



...cleaning rod



M240 MG Cleaning



NEXT TIME YOU CLEAN AND LUBE YOUR M240 MACHINE GUN, HOLD ON TO THIS THOUGHT...



Back Plate


It's not necessary to take apart the back plate for cleaning. Fact is, it's not authorized.

For instance, if you do take it apart and lose or forget a buffer washer, the back plate will take a beating from the bolt and operating rod. The buffer needs all 11 washers to handle the shock ...and they must be installed in the right order.



Trigger Assembly

Also, stay away from the trigger assembly.




You never take it apart to clean or lube it. Best advice is to stay out and let support do any necessary trigger disassembly.

Crewmen and armorers take it apart and can't get it back right. When you assemble the trigger wrong, you might not be able to move the safety, the weapon won't fire...or you could set up a runaway gun.

Barrel

One thing you can do is to make sure the barrel is fully seated in the

shouldn't have to force the barrel release to lock.



receiver before you try to lock the barrel release. That saves stripped threads, usually in the receiver.

When the barrel's seated, you



If you can lock the release with fewer than 2 clicks, or it takes more than 7 clicks, have your support check it out. Something's wrong.

DIDJA HEAR TH' LATEST?



Small Arms Get **RCM** Nod

Reliability Centered Maintenance, the Army plan to cut out unneeded maintenance work for troops, has tapped small arms Preventive Maintenance Checks and Services (PMCS) for a big cutback.

Weekly PMCS for weapons of .50-cal and under will be extended to quarterly when new TM changes and revisions come out.

Table 3-3. Preventive Maintenance Checks and Services

Item Number	Interval Operator				Item to be Inspected	Procedure	Reference
	B	D	A	W			
Change to quarterly	X			X	Machine Gun	Assure conformance to lubrication instructions. Field strip to insure that all moving parts are clean, lightly oiled and function freely. Assure gear	Table 3-2

It'll take awhile for the pubs to get out. Meanwhile, your command can make weapons' PMCS's quarterly right now.

However, weapons stored in high humidity or dusty areas need to be cleaned and lubed more often when necessary.

M3A1 Barrel Nicks

OUCH!!



I'VE BEEN NICKED AGAIN!

WE'LL SEND YOU TO DS!

Next time you take your M3A1 submachine gun down for cleaning, eyeball the chamber end of the barrel for nicks and burrs.




Check for nicks and burrs

Nicks and burrs can make the gun jam. They should be checked and possibly smoothed off by your support.

A reminder: First, press down on

the barrel ratchet spring. Then, turn the barrel collar to release the barrel.



Press down here...

...then turn collar to release barrel

To install the barrel, first press down the spring. Then, turn the collar.

That saves chewing up the notches on the collar and the receiver.

M16A1 Coverups



DEAR MOM,
ABOUT MY EPC...

EPC Spring

Repair point: When you install the EPC spring, both ends of the spring stay on the inside of the cover.

The short end rests against the upper receiver, and the long end stays in the groove on the inside of the cover.


Ejection Port Cover

The ejection port cover (EPC) of your M16A1 rifle can do an armorer or rifleman good...or do either one dirty.

It all depends on you.

For instance, after you separate the upper and lower receivers for cleaning or maintenance, eyeball the EPC.

Before you re-attach the upper receiver to the lower, be sure the EPC is




Close cover...

...then, join receivers

closed. Otherwise, the lower receiver will jam into the EPC, bend it and maybe even damage the receiver itself.

Close cover, put receivers together.



Short end

Long end of spring

Both ends stay on the inside of the cover!

If you install it wrong, you'll have trouble keeping the cover open...or in closing it. You may even break the spring.

Flash Suppressor

Never remove the flash suppressor for cleaning or repair. Installing or removing it the right way takes special tools. That's a support job.



Never remove the flash suppressor yourself!

P O B S

This is a selected list of recent pubs of interest to organizational maintenance personnel. This list was made from a computer printout provided by The Adjutant General.

Miscellaneous

AR 385-95 Nov Aviation accident prev SC 6720-95-CL-A02 Apr Camera set, still picture: EOD
TB 9-2300-420-20-1 Nov M48 and M60 tanks parking brake sys maint
TB 9-2350-257-20-1 Aug Troubleshoot 650-amp charging system, M60A1 RISE
TB 380-40-1 Jan Security TSEC/KY-65, TSEC/KY-75 (V)
TB 380-40-5 Jan Security TSEC/KG-45 (U)
TB 750-651 Jan Antifreeze, cleaning compounds in engine cooling systems.

Technical Manuals

TM 5-2805-261-13-HR Nov AAL: Outboard motor, gas, OMC Mod AM-40A
TM 5-4610-215-10 Oct Water purif unit, reverse osmosis; 600-GPH Mod ROWPU 600-1
TM 9-1425-484-10-HR Oct Dragon M47
TM 9-1430-655-20-7-2 Oct AN/TSO-73
TM 10-8110-201-14&P Feb Drums, fabric collapsible non-vented; 500-gal, 250-gal, 55-gal
TM 11-5805-638-12-HR Nov Bit: Multiplexer TD-1069/G
TM 11-5805-711-24P Nov Multiplexers AN/FCC-88 (V) 1, AN/FCC-93 (V) 1X
TM 11-5820-894-14 Aug Terminal, radio AN/TRC-151 (V)
TM 11-5821-285-12-1 Sep Comm centrals AN/ASC-15A (V) 1, AN/ASC-15A (V) 2

TM 11-5895-824-12 Aug Interrogator set AN/TPX-46 (V) 7
TM 11-5895-1124-24P Nov Converters, freq electronic CV-3655/G, CV-3654/G
TM 11-5895-334-20P-1 Nov Mast antenna AB-621A/G, extension kit MK-2044/G
TM 11-5895-362-13 Sep Antenna gp OE-317/TSC-99
TM 11-6625-2954-24P Nov Signal generator SG-1144/U
TM 11-6625-2974-10-HR Nov Radar test set gp OQ-270/APS-94F
TM 11-6940-211-10-HR Oct Simulator, radar signal SM-674/UPM, test adapter, radar signal MX-9848/APR-39 (V)
TM 11-7440-308-12-1 Oct CRT terminal systematics gen Mod T-51456 and Hewlett-Packard graphics terminal 2648A
TM 55-1520-240-CL Nov CH-47D
TM 55-1520-240-PM Aug CH-47D

AUDIO-VISUAL STUFF

Available at battalion or post Learning Center

TEC Lessons

030-051-6446-F Bailey bridge
030-051-6453-F Bailey bridge
Part II
030-051-6454-F Bailey bridge
Part III
030-051-6457-F Assemble medium girder bridge
030-051-6460-F Assemble

single story medium girder
030-051-6468-F Load, secure medium girder bridge; Part II
030-051-6469-F Load medium girder bridge pallets
030-051-6497-F Assemble tactical raft
030-051-6498-F Install tactical raft deck and filler panels

043-441-1066-J FAAR, data link system monthly, quarterly checks
043-441-5552-F IBCC scan servo gear train alignment, Part II
000-011-6630-F Rig engine controls for N1 RPM
644-093-7094-A Periodic in-

spec LANCE warhead sect, Part II
644-093-7109-A Inspect Pershing warhead
644-093-7114-A Inspect Pershing warhead
644-093-7194-A Safety wire procedures
945-171-0093-F Track vehicle recovery

Replacement Strap NSN

Use NSN 5340-01-114-7712 to get a safety strap that's long enough for your 2½-ton or 5-ton cargo truck. This replaces NSN 5340-00-536-0186 and NSN 5340-00-594-8032.

Missile Readiness Criteria

Looking for readiness rating criteria for components of missile systems? The word's in AR 750-40, Army Missile Materiel Readiness Report.

Award for Maintenance Excellence


Winners of the Chief of Staff's first annual Army Award for Maintenance Excellence will be announced 29 Mar 83 at Aberdeen Proving Ground.

The word will be put out at the Total Army Worldwide Maintenance Conference to be held at the Army Ordnance Center and School 28-30 March. Theme for the conference will be "Maintenance—Master Plan for the Future". Attendees will be from major Army commands, divisions and Reserve Forces.

Information on the maintenance conference can be had by calling AUTOVON 288-5118/5222.



BEAT Terminal Illness



More engine starting trouble comes from bum battery hookups than anything else! Right there—where the cable terminal, battery clamp and battery post come together—is the first place to look when you're troubleshooting for starting trouble.

On the civilian side, towtruck operators make a fortune just cleaning and tightening bum battery hookups when engines won't start.



There's no good reason for starting trouble caused by loose or dirty battery hookups.



Battery Hookups...

IT'S REAL SIMPLE...

1 If you've got to take off the battery ground cable for troubleshooting or repairing the electrical system, take the cable terminal off



the clamp—**not** the clamp off the post. Then you won't upset a good clamp-to-post connection.

2 If there's some reason for taking the clamp off the post, use the lifter tool, NSN 5120-00-944-4268, in your No. 1 Common Shop




Equipment. Never try to pry the clamp off with a screwdriver or some other tool. You'll most likely bust a hole in the top of the battery.

Make sure you've got a good connection when you put the clamp back on. You need maximum contact between the clamp and post to get full power out of the battery—and also to get full power into the battery when it's being recharged by the generator or alternator.

CHECK THESE POINTS...

- The taper of the battery post and the taper inside the clamp



must match. The positive (+) battery post is a little bigger than the negative (-) post, so you've got to have the right clamp for each post to get max contact.

- Replace a clamp that's broken or so badly bent out of shape that it won't fit on the post right.

No good—replace it!



- Clean the inside of the clamp and the outside of the post so they're bright 'n' shiny. Use the




cleaning tool, NSN 6140-00-831-3449, in your No. 1 Shop Equipment.

- Get the clamp all the way down over the post. But never hammer it down; you'll bust up things inside the battery. Get your



support to make you a tapered spreader tool from 1-in diameter bar stock. Use the tool to spread the clamp so it'll fit easily on the battery post.

- Use 2 wrenches of the right size to tighten the clamp bolt and nut. Never—but never—use an adjustable wrench. It'll slip off and



punch a hole in the battery top. When the nut's just snug, give it only a 1/4-turn more. If the clamp takes a self-locking shoulder nut,

make sure the shoulder end is away from the clamp. You need



Shoulder end of the nut should be away from the clamp. Like so...


full nut pressure on the clamp. Besides, the shoulder end will dig into—and tear up—the clamp.

- Smear a light coat of grease (GAA) all over the clamp and post



to head off corrosion. Some people think the GAA goes on the post before the clamp goes on. Wrong! That makes for mighty poor contact between the clamp and post.

3 When you mount a cable to a clamp, put the cable terminal under the bolt head. If it's under the nut, cable bounce will loosen the nut. If 2 cables go on the



clamp, you can put the second cable under the nut. Then use plastic hanger straps, NSN 5975-00-074-2072, to keep the cable from bouncing.

Let's Stop



Battery Abuse!

2 OUT OF EVERY 3 LEAD-ACID BATTERIES IN THE ARMY WILL BE KILLED BY ABUSE AND NEGLECT!

UNLESS, OF COURSE, WE END THIS MINDLESS DESTRUCTION AND STAGGERING COST!

WITH YOUR COOPERATION, WE CAN STOP THIS WASTE OF RESOURCES, MONEY, TIME AND EFFORT!

About one-third of those are destroyed through physical abuse!

Dropped on hard surfaces!

OUCH!

OWW!!

Posts ruined by hammering or prying on the clamps!

Holddowns too tight... ...or too loose!

ARR-RRGH!

Another third die of plate sulfation—plain ol' neglect!!!

Batteries are left undercharged with no electrolyte over the tops of the plates!

HALF-MAST, BONNIE AND I WILL BE DOING ALL WE CAN TO HELP YOU WIN THE FIGHT AGAINST BATTERY ABUSE!

THE QUESTION WE MUST ALL ANSWER IS THIS...

IF WE CAN'T TAKE CARE OF OUR BATTERIES, HOW CAN WE POSSIBLY TAKE CARE OF A MISSION?

Joe's DOPE

The Case of The Castoff Cable

I SAY, OLD
FRIEND... WHERE
ARE WE?

AH--MY DEAR WATSON,
WE ARE CLOSE BY AN
IMPORTANT CLUE...

INDEED... THERE--
JUST AHEAD...

FOUL PLAY HERE,
WATSON! ANOTHER
EXAMPLE OF MAN'S
INHUMANITY TO
CABLE!

JUST SO, HOLMES!
ANY CLUES TO THE
CULPRIT'S IDENTITY?

YOU DISAPPOINT ME!

CLUES ABOUND!

OBSERVE,
MAN,
OBSERVE!!

FOR THIS CUT,
WATSON...

START LOOKING FOR
A COMMO SITE WHERE
CABLES CRISS-CROSS
THE GROUND!

A FEW TRIPS BY A
TRUCK OR TANK CUT
EVEN THE TOUGH-
EST INSULATION!

OF COURSE!
BUT HOW
COULD THEY
HAVE AVOIDED
THIS CABLE
CRIME?

EASILY, WATSON!
PUT THE CABLE
OVERHEAD OR
UNDERGROUND...

A SHALLOW TRENCH OR CULVERT
SAVES MANY A CABLE!

...AND
OVERHEAD?

FM 24-20 HAS CLUES ON STRAIN
RELIEF AND SUCH...

String cables at
least 18 ft above
roads

SAG IS
IMPORTANT,
TOO...

MY RESEARCH HAS
ESTABLISHED THE
SAG PER FOOT ANY
CABLE NEEDS...

DEVILISHLY CLEVER,
HOLMES!

Span in feet	100	125	150	175	200
Sag in inches	16	24	36	48	72

HALLO! LOOK HERE, WATSON
... THE CABLE'S BEEN
MASHED!

DASTARDLY, HOLMES!

THE RADIO CABLES WERE UN-
PROTECTED AS THEY CROSSED
CARGO AND SEATING AREAS!

EXACTLY RIGHT, WATSON! A QUICK READING OF
SB 11-131, VEHICULAR RADIO SETS AND
AUTHORIZED INSTALLATIONS* ALONG WITH
THE INSTALLATION KIT PUB (TM 11-2300 SERIES)
GIVES TROOPS THE SHIELDS AND GROMMETS
THEY NEED TO SAVE THEIR CABLES!

HERE'S
ANOTHER
VICTIM...


HAMMM--
PRETTY
CAMOUFLAGE,
ISN'T IT!

Shields help

Grommets
can
save
cables


* Ed Note: This pub's not up-to-date. If
you need info on an installation kit
not covered in SB 11-131, write to:

US Army Communications-Electronics Command
ATTN: DRSEL-ED-SM
Ft Monmouth, NJ 07703



Dear Editor,

We made a fail-safe puller for removing the plastic sight gage glasses on all Bell choppers. The one shown on Page 43 of PS 332 has a tendency to slip, and there is no puller in our tool kits.



We made our puller from 1 1/2-in aluminum round stock, about 6 inches long. It's real easy to make and will prevent glasses from being damaged from using other removal methods...saves on replacement costs.



To use the tool, just insert it over the sight glass, tighten the wing nut, and p-u-l-l. That's all there is to it!

SGT Jerold L. Fry
Ft. Bliss, TX

(Ed Note—Your tool looks like a winner, Sarge!)

Maintenance Platforms...


FACE IT, BIRD MECHS... NO. 1 MAINTENANCE STARTS WITH YOUR TOOLS... AND YOUR B-1 PLATFORM IS YOUR NO. 1 TOOL!



Front 'n' Center!

YOU GOT IT, BONNIE!! THEY CAN'T FIX IT IF THEY CAN'T REACH IT!

Eyeball the hydraulic lines and fittings for leakage. A loose line or fitting can easily be tightened to stop a leak. If a line is blistered, cut or frayed, replace it before it fails.



Lines leaking?


Check the hydraulic fluid level. Add fluid, if necessary, to bring the level up to 1 inch below the filler



Fluid level OK?

neck. Use hydraulic fluid, MIL-H-5606, NSN 9150-00-252-6383.

If there's no tread on the tires, or if they're cut, replace them. The tire pressure should be 40 PSI.



40 PSI needed!

Plant your brogans on the 2 immobilizing jacks to make sure the platform won't move when it's in place. If foot pressure doesn't easily set the jack pads, grease the pivot points on the mechanical jack.




Use grease here!

Pump up the platform to make sure you get the lift you need. Always



Pump'er up!

set the hydraulic cylinder lock in place after you raise the platform.



Set lock!

Otherwise, a hydraulic failure will give you a sudden letdown.

Eyeball the base of the platform to




Weight stencil

make sure the stenciled 500-lb weight limitation is readable.

IF YOU HAVE THE NEW B-1 PLATFORM, NSN 1730-00-529-6235, FOLLOW THE INSPECTION INFO IN TM 55-1730-223-13!

Platform complete...

...handrails in place?



Save the Bearings!

DID YOU FINISH YOUR PMS?

YES, SIR -- AND I CLEANED THE BIFILAR WEIGHTS AND TH' DAMPER BEARINGS WITH ONLY A CLEAN, DRY CLOTH -- OUR NEW SOP!

The Black Hawk main rotor head damper bearings are taking a beating, bird mechs, because petroleum products are getting on the Teflon liner.

What happens when oil, for example, and Teflon meet? Plenty—all bad! The liner swells up and collects dirt. The grit starts chipping the Teflon and the bearing soon becomes unserviceable.

The bearings are being ruined because some mechs are spray-cleaning the bifilar weights. The spray drifts

down onto the damper bearings, which are right under the weights.

Instead of an aerosol can, use a clean, dry rag to wipe off dirty grease. Then, according to Sequence 6.8 in TM 55-1520-237-PMS-1, use Lubriplate 630-AA on the weights. NSN

Use clean cloth, Lubriplate on weights



9150-00-663-1770 will get you a 5-gal pail of Lubriplate.

To clean the damper bearings, use a clean, dry cloth.

Remember—your UH-60A rotor head is loaded with "lollipop" bearings that have Teflon liners. Except for the bifilar and swashplate, no lube is allowed on the rotor head.

I BROUGHT TH' ENGINE STARTER OIL LEVEL UP TO TH' BRIM!

...AN' I ADJUSTED TH' APU START NOZZLE, CHIEF!

Fill It to the Brim!

Be sure you crew chiefs check the oil level in the Black Hawk engine starter during your 7-day, 10-hour Preventive Maintenance Service.

If that baby is low on oil, the internal clutch assembly will fail and shear the drive shaft.

To prevent a starter change, add MIL-L-23699 oil to the point of


overflowing. The word on servicing the installed starter is on Page 20, Sequence 6.19, TM 55-1520-237-PMS-1.

The overflow level is required because the filler neck of the installed starter is at the 11 o'clock position.

Bench Check

The filler neck on an uninstalled starter, tho, is at the 12 o'clock position on the workbench. So the word in Task 5, Step 1 of TM 55-1520-237-23-6 is to drain the reservoir and add 190-210cc of oil. You don't fill it to the brim.

Either way, you want the right oil level in the engine starter.




The Right Pattern

The fuel spray pattern into the Black Hawk auxiliary power unit has to be just right, knucklebusters, to fire up that baby.

If the start nozzle is inserted too far (or not far enough) into the combustion chamber, the spark plug won't ignite the fuel.

For the right pattern, insert the nozzle until it just bottoms in the chamber. Then, back it out 2 to 2½ turns. Torque the jamnut to 35-40 lbs-in.

You'll find that important info, and more, in Task 20, Step 14 of TM 55-1520-237-23-6.




Adapter Here



If you've been looking for the new adapter and socket wrench to use on the OH-58A/C main rotor mast nut, it's now in supply.




Socket, NSN
5120-01-098-4475



Adapter, NSN
5120-01-098-4541

To use the special tools, insert the socket over the nut, add the adapter,




insert the drive bar, and place your Power-Dyne torque wrench in position.

Make sure the main rotor blade tiedown has been removed so both blades are level.

A little hand action on a socket wrench will get you the 250-270 lb-ft torque needed on the nut.

Make the Seal



If the foam rubber seal on top of the OH-58A/C oil cooler has had it,



Kiowa mechs, you can't get one by ordering from the parts pub. The Source, Maintenance and Recoverability (SMR) code says you have to make it.

You'll find seal dimensions and the material to make it in Figs D190, D191, and D192 of TM 55-1520-228-23.

Also, Fig 52, Items 33A, 33B, and 33C in TM 55-1520-228-23P, is being corrected to show the right location for the seal.

For U-21, U-8 Aircraft...

Gear Down and Locked?



If the landing gear indicators on a T-42A indicate the wheels are not down, maybe only the indicators are faulty.

If so, Cochise pilots have a backup system. It's a wide-angle (convex) mirror on the inboard portion of an engine nacelle. It's shown in Fig 2-1 as Item 11, TM 55-1510-208-10.



U-21 and U-8 airplane drivers can also use a mirror, positioned to show the gear from the cockpit.

Mirror, NSN 2540-01-079-3327, has an adhesive backing. Put it on an engine nacelle where you can get a good bond and a look if a gear emergency arises.

Aviation Messages

Cat 1 EIR Phone:
AUTOVON 693-2086
(24 hours)

If your unit has not received a message in which you have an interest, check with your next higher headquarters.

AH-1-82-11 Maint Advisory—Flatplate canopy removal detonation transfer 051930Z Oct 82

AH-1-82-12 Maint Mandatory—Wiring clearance of AN/ALQ-144 IR jammer AH-1S (Modernized Cobra) 081300Z Oct 82

UH-1-82-05 Maint Mandatory—replace safety relief valve with plug UH-1B/H/V, EH-1X 011600Z Oct 82

UH-1-82-06 Emergency technical—connecting link, rigid, left, right cyclic 072230Z Oct 82

UH-1-82-06 Revision to emergency—technical connection link, rigid, left, right cyclic 082100Z Oct 82

CH-47-82-13 Maint mandatory—CH-47A/B/C/D engine fire extinguisher cartridge 221430Z Oct 82

CH-47-82-14 Technical—status of op capability of CH-47 fleet 232000Z Oct 82 UH-60-82-18 Maint mandatory—main rotor spindle droop stop 272105Z Oct 82

UH-60A-82-19 Maint mandatory—Yaw trim and roll trim servos improved seal 221430Z Oct 82

OH-58-82-03 Maint mandatory—anti-icing valve poppet seat screw T63-A-5A1 700 and T63-A-720 engines 071530Z Oct 82

GEN-82-07 Maint mandatory—airworthiness directive (AD) 82-20-01, 19 Sep 82 272102 Oct 82

AH-1-82-10 Maint mandatory—maint inoperative 10-KVA alternator, 051925Z Oct 82



High-Security Padlock

More 'n' more you're seeing the shrouded shackle padlock, NSN 5340-00-799-8248, on arms room doors.




HERE'S THE PM HOW-TO THAT'LL KEEP 'EM SERVICE-ABLE FOR YEARS!

OH, THAT'S ANGUS, CONNIE --SAYS HE'S A BROWNEE EXPERT ON LOCKS!

Shrouded Shackle PM

You can open the lock by turning the regular key only one way—clockwise 45 degrees. Never force it. Never use the key ring or pliers to turn a key. You'll break off the key in the keyway, and that's a peck o' trouble. Always be sure the key is all the way in before turning it.



Turn the key to the right. When it stops, pull the padlock away from the shackle. It won't spring open because it has a dead bolt shackle.


You can't remove the key when it's in the unlocked—open—position. So, don't try!

Be careful when you get ready to remove the key after locking the lock. Turn the key back to the original position. Watch it. On some HSP's if you turn 'em to the left as far as they'll go, a shoulder projection will




catch on the base of the padlock case. You won't be able to pull the key out. This won't happen on the newest locks.

High-Security Padlock




So, ease the key to the right a smidgen till the shoulder projection is clear, then pull the key straight out. No bending, please.

Never use the control key unless you want to service the cylinder, bolt and inside of the case.



The control key will also unlock the padlock if you turn it 45 degrees to the right. But to release the cylinder and bolt, turn the key 45 degrees to the left. Pull the padlock away from the shackle. Remove the cover and key. Now hold the padlock upside down in your hand and shake the lock until the bolt and cylinder drop into your palm. The shackle will not come loose from the case.



If the cylinder doesn't come out, rap the lock gently with a plastic, rawhide or lead mallet. Use holder, inserted hammer face, NSN 5120-00-903-8546, with the medium plastic flat face insert, NSN 5120-00-293-3003, for this job. Hammer and face insert are in your Small Arms Repairman's Tool Kit.

Now, Together

Here's how to put the shrouded shackle padlock together. Hold the lock in the left hand with the shackle



curving over the knuckles. Slide the cylinder into the lock. The projection




on the cylinder faces the side away from the shackle, and fits into a recess in the side of the case.

Now for the bolt. Lift the shackle with the thumb as high as it'll go. Use



round-nose pliers to place the bolt—with the nipple on top facing the

shackle—in the lock and let it rest on the cylinder.



Getting the cover in place is the hard part. Here's how to do it:

Hold the bolt down on the cylinder with your finger or thumb. Hold the HSP upside down and let the shackle drop. Insert the control key in



the keyway and turn counterclockwise 45 degrees. The shackle will drop down when you turn the control key. No sweat. This moves the bolt out of the way so the cover can slide easily into the hole.

A GOOD LOCK IS NOT THE RESULT OF GOOD LUCK... BUT OF GOOD PM!

WE'RE FROM LOCK LOMOND...

...I'M FROM LOCK NESS!

Slide the cover into place. Hold it there with your thumb and turn the HSP upright. Now pull up the shackle as far as it'll go, swing it counterclockwise and drop it into the lock. Turn the control key to its original position and pull it straight out. Again, no bending.



"LOCK-IN" ON THIS PM INFO AND KEEP THOSE SHROUDED SHACKLE PADLOCKS TROUBLE-FREE FOR YEARS!

I NEED A BAGEL FOR MY LOCKS!

HSP, MSP Repair



Want to save a bundle of bucks on replacement of medium- and high-security padlocks?

Replace the cylinder only!


If your keys are broken or lost, or the cylinder's damaged, you can rebuild your locks with a new cylinder. NSN 5340-01-127-0989, PN S23-500X2, gets you a replacement cylinder and 2 keys on an exception data request. Cost is \$13.45.

The NSN is not on the AMDF.

The cylinder fits high-security padlock, NSN 5340-00-799-8248, and

medium-security padlocks, NSN 5340-00-799-8016 and 5340-00-492-1993.

The cylinder won't fit the new medium-security padlock, which looks like this:





A lot of clothing bags and non-insulated pneumatic mattresses are being turned in as unserviceable when they're still perfectly good.

Waterproof clothing bags—NSN 8465-00-261-6909—have been turned in with pinhead-size areas that

waterproofing material. They do not make the bag unserviceable.


Insulated and uninsulated pneumatic mattresses are showing up at property disposal with repairable leaks.

Para 2-7, TM 10-8400-201-23 has the inspection and repair poop for the bag and mattress.



are visible when the bag is held in front of a light. Troops think these are holes, and that the bag is a leaker.

Not so. These thin areas in the bag are gaps in the synthetic rubber



Use the cold weather insulated boot maintenance kit, NSN 8465-00-753-6335, to repair small rips and holes in these 2 items.

Jumper Cable Clamps

NSN 5999-01-046-9397 gets a pair of 800-amp rated, heavy-duty clamps—1 positive and 1 negative. Use them to replace missing or damaged clamps on the jumper cable, NSN 2920-01-027-0125, that's in your No. 1 and No. 2 Common shop sets.

Order them on DD Form 1348-6 and add in the Remarks Block that the clamp number is on the AMDF, but with some missing information. The RIC is S9E, price \$10.95.

NEED 'EM? THEN JUST...

48

Mobile Field Kitchen...

Take the 'Sink' Out

WHERE'S TH' SINK IN THIS KITCHEN?


UNDER TH' LEVELING JACKS!

Do you have that "sinking" feeling when the leveling jack pads on your MKT-75 trailer-mounted field kitchen sink into soft ground? Are the jacks too short to level your kitchen on rough ground?

You can head off these problems by making up a set of 12-in or so square pads to use under the leveling jacks.

Make them out of a ½-in thick steel plate, like NSN 9515-00-294-9916, or out of 2 layers of 2-in lumber nailed together.

Use the pads when you set up on uneven or soft ground.



Kitchen Trailer

If a cold, slick floor is a problem in your trailer-mounted field kitchen, the answer is in C3 of TM 10-7360-206-23P. NSN 7220-00-034-7225 gets you a roll of rubber floor matting.

Battery Cover Care

Never step on the battery box cover when you get in or out of the 27-ft bridge erection boat cockpit.

You'll bend the hold-down bolts and push the cover down until it hits a positive terminal post. Then, the battery will arc and burn a hole in the cover.




49

D7E/F Caterpillar...

Check for Rock Damage



A rock lodged between your Cat's sprocket segment gear mounting bolts and the final drive housing can wear a hole in the housing PDQ.



Your tractor loses oil, your MO loses his cool, and your unit loses the equipment for a bunch of days.

Sequence 11, Table 2-1, PMCS in TM 5-2410-233-20 says the final housing is checked for leaks every quarter.

But when you're working in sticky, heavy stuff, clean out this area shortly after each operation. Don't allow your Cat to sit around idle until packed-in mud, rocks and debris harden in place.

Also, when operating in heavy mud or clay, with very few rocks, don't use roller guards. While they keep rocks out, they keep a lot of mud and clay in that would otherwise fall by the wayside.



NOTHIN' TO IT! I USETA OPERATE TH' ROCKET AT ADVENTURE-LAND!

JD 410 Backhoe

Your JD 410 backhoe-loader is hardly a Formula 1 racer. Driving it over 5 MPH will crack it up faster than a smash into a high-bank Indy turn.

This loader has no suspension system for shock protection so every bounce 'n' bump takes its toll.

Soon the vehicle's rear axle retaining bolts are loose and damaged, the axle comes loose and slides out of its



H100C Scoop Loader... Alcohol Injector Kit

Stop brake system freeze-ups on your 4½- and 5-cu-yd IHC scoop loaders with this alcohol injector kit and attaching hardware:



PN	Item
a. 890062C93	Alcohol evaporator-kit
b. 3-8X1 N	Bolt (2)
c. 3-8 R	Washer (2)
d. 3-8 X	Nut (2)
e. 55916R11	Elbow

USE DD Form 1348-6 AND FSCM 29510 FOR THESE ITEMS! THE RIC IS 59C!!

Section 13 of TM 5-3805-255-14&P has the injector kit installation info. Page 2-28 of TB 43-0001-41-6 (Jul 81) authorizes the kit.



20-Ton RT Crane

Use NSN 4720-00-459-5945 for the coolant line elbow, Items 24 and 26, Fig 146, TM 5-3810-232-20P.

Plumber's Antiseize Tape

Use NSN 8030-00-889-3534 (¼-in) or 8030-00-889-3535 (½-in) for a 260-in roll of antiseize and sealing tape for pipe threads on liquid and gaseous oxygen systems of 2,000 PSI or less.

Safety Tips

housing. Your high-speed run has damaged the axle, bearing, seals, housing, planet pinion housing gears and differential!



Connect the brake pedals with the brake pedal bar at high speeds—

- Make turns at very slow speeds.
- Read 'n' heed the safety rules in the Operator's Manual CJT-26116B.

No Identity Crisis Here

ECC, ERC and LIN may sound like the cast for a science fiction movie, but they're not.

They're codes that help you and the headshed identify your equipment. You use the codes on a variety of TAMMS and supply records.

HI!
I'M
AN
ECC!



THEY
CALL
ME
AN
LIN!

J85313

...AND
I'M
AN
ERC!



HERE'RE SOME
OF THE PLACES YOU'LL
USE THESE CODES...



ECC

ECC stands for Equipment Category Code. It's a quick way to group equipment by type.

The ECC is made up of 2 letters. The first one identifies the equipment's primary category—aircraft, missile, vehicle, etc. The second letter ties the item to a specific size or class.

For example, the ECC for an M151A1 ¼-ton truck is HB. H is the letter used for tactical vehicles and B identifies most ¼-ton trucks.

You'll find a complete list of ECC's for your equipment in TM 38-750, Appendix A, Table A-20.

LIN

The LIN, or Line Item Number, identifies a group of items that do the same job, but have different NSN's.

The LIN is made up of 6 characters—one letter and 5 numbers. The numbering system runs in sequence from A00001 to Z99999. The letter O is skipped because it can easily get mixed up with zero in data processing.

Every item on your MTOE has an assigned LIN. You'll find them in column b of the MTOE.

LIN's for your DA Form 2406 reportable items are listed in TM 38-750, Chap 4, but for a complete list of items with LIN's, check out SB 700-20.

ERC

Next to the LIN's in your MTOE you'll find the Equipment Readiness Codes (ERC's).

Code A identifies primary weapons and equipment; B, auxiliary equipment; and C, administrative support equipment.

The code assigned to the equipment in your unit is based on how essential the equipment is to your unit's mission.

A ¼-ton truck with radio, for instance, may be ERC-A for an artillery battalion and ERC-B for a tank battalion.

Some items, like NBC equipment, are common to most units and carry the same readiness codes on all or most MTOE's.

MATERIEL CONDITION STATUS REPORT
For use of this form, see TM 38-750; the reporting agency is GCSLOG.

1. PERIOD OF REPORT FROM: TO:		2. DATE PREPARED		3. UTILIZATION CODE		4. PAGE NO.		4b. NO. OF PAGES	
5. TO: (Include ZIP Code)		6. FROM: (Include ZIP Code)		7. UNIT IDENT CODE		8. TOE NO.			

SEQ NO.	NOMENCLATURE		ECC LIN	AVAILABILITY STATUS (ITEMIZED)			EQUIPMENT AVAILABILITY			FOR FIELD USE ONLY						
	NAME	MODEL		AUTH QTY	ON HAND QTY	POSSIBLE DAYS	AVAILABLE DAYS	NONAVAILABLE DAYS	REQ QTY	REQ DAYS	FB	ER	ERC			
1.	Truck, Cargo 1½-T	M561	HF X39740													
2.	Truck, Cargo 2½-T	M35A1	HG X40009													B
3.	Truck, Util ¼-T	M151A1	HB X60833													B

ECC	LIN	ERC
DD Form 314 (reportable gear & subsystems only) DA Form 2406 Property book records	DD Form 314 (reportable gear & subsystems only) DA Form 2406 Property book records	DA Form 2407 DA Form 2406, DA Form 2715 Property book records

DA FORM 2406 MAY 81

EDITION OF DEC 79 IS OBSOLETE.

Don't let the "alphabet soup" of these codes throw you. Once you're straight on what the codes are, they save you a lot of time and effort.

THEY'RE JUST
A SHORTHAND
WAY OF
IDENTIFYING
YOUR GEAR!



Antifreeze...

Stencil No More!

NO, NO, MERVIN!
YOU ONLY REFRAIN
FROM STENCILLING
ANTIFREEZE
INFO!



AW
SHUCKS!!

The Supply and Maintenance Assessment and Review Team (SMART!) message on the DA Form 2408-1 told you to stencil antifreeze info on your gear.

But there's been some re-thinking on that! The antifreeze check is part of a scheduled service in most equipment TM's and in TB 750-651, Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling Systems. Also, you now change the antifreeze only when it fails the test.

So you need no special record of antifreeze testing—usually!

Forget the stencil requirement on antifreeze.

In fact, forget any special record of testing and degree of protection of antifreeze except when your equipment is under warranty or you're using:

- Commercial antifreeze
- Arctic antifreeze

If you put commercial or arctic antifreeze in your gear or the gear's under warranty, keep up with the test results and protection in the Remarks Block of the DD Form 314.

Hold it! There's 1 more "special case"! PS 354, Pages 26-27, tells you about extending the antifreeze by boosting the rust protection. That's a one-time deal. Add that action to your DD Form 314 Remarks!


Appendix B
of TM 38-750...

Fill in the Holes

GOOD NEWS, BUDDY! WE
CAN FILL IN SOME OF
YOUR HOLES NOW!



AHHHHH --
GREAT!!



Fed up with holes in your address book for SF 368 Equipment Improvement Recommendations (EIR's) or Quality Deficiency Reports (QDR's) and DA Form 2407 Warranty Claim Actions (WCA's)?

Well, grab a pencil. Turn to Section II, Appendix B of TM 38-750 and fill in some holes!

Add these Federal Supply Classes (FSC's):

1070-1080	6210-6350
3210-3230	6670-6675
3455-3470	7105-7720
5410-5411	8305-8475

FSC's are the first 4 numbers of NSN's.

NOW MAKE A NOTE
TO SEND ALL YOUR
SF 368's AND WCA's
ON ITEMS WITH THOSE
FSC's TO...



Commander
US Army Troop Support and
Aviation Materiel Readiness
Command
ATTN: DRSTS-MPSD
4300 Goodfellow Blvd.
St. Louis, MO 63120

Troubles? Tell Half-Mast

Got maintenance or
supply troubles?
Let Half-Mast know.
Just jot a note to:
MSG Half-Mast
% PS Magazine
Lexington, KY
40511



Got some hot questions on supply
regs or policy?

The Logistics Evaluation Agency (LEA) has a 24-hour hotline to help you.

Give 'em a call on AUTOVON
977-6842 or commercial (717) 782-

Supply Hotline

6842 if you have questions on these
regs:

AR 710-2
AR 735-5
AR 735-11
AR 735-11-1
AR 735-11-3
AR 735-17
AR 735-20
AR 735-72
AR 750-1


HAVE THIS INFO READY WHEN
THEY ANSWER THE PHONE...

- Your Name
- Your Rank
- Your Telephone Number
- Your Unit Address
- Regulation Number and Paragraph in Question



1 Block for 1 Index

I MAY LOOK LIKE A PUNY WEAKLING, BUT I PACK A WALLOP LIKE THE BIGGEST PUB!



Almost all the pubs and forms you'll ever need are in 1 index: DA Pamphlet 310-1, Consolidated Index of Army Pubs and Forms (Fiche).

For now, you get as many copies of the consolidated index as you marked for any of the indexes it replaced. That is, you'll get as many DA Pams 310-1 as you marked for

DA Pam 310-1, -2, -3 and -4 on the DA Form 12-4.

But in the future, your copies will be based on how many you've marked in Block 17 of DA Form 12-4—for the DA Pam 310-1 alone.

Make sure your unit keeps up with the times—and pubs—and for enough copies to meet your needs!

Re-View the UIC

WISH WE'D GET OUR NEW BIRD SOON...

THURMOND, YOU SURE YOU BEEN FILLIN' OUT BLOCK 6 ON OUR DA FORM 1352 CORRECTLY?



You aviation types know a lot rides on the monthly DA Form 1352, Army Aircraft Inventory, Status and Flying Time Report.

But do you know how important a good Unit Identification Code (UIC) in Block 6 is? The experts use the UIC to figure flying hour costs for each unit and to keep tabs on where the birds are. It also helps tell them who needs new birds.

A slipped digit in your UIC could mean you lose your place in line for newer aircraft. Doublecheck the UIC before you send in the DA Form 1352.

Generator Operator Training

WANT TO SET UP A PROGRAM TO TRAIN GENERATOR OPERATORS?

HERE'RE THE BASIC PUBS YOU NEED TO GET THE CLASS STARTED...



Publications

Title

AR 700-72	Mobile Electric Power
AR 385-30	Safety Color Code Marking and Signs
DA Pam 750-1	Maintenance Guide for Leaders
FM 20-31	Electric Power Generation in the Field
FM 43-1	Organizational Maintenance Managers Guide
FM 43-1-1	Organizational Maintenance Managers Guide Indicator List
TB MED 501	Noise and Conservation of Hearing
TB 385-4	Safety Precautions on Electrical and Electronic Equipment
TB 43-0125	Hookup of Electrical Cables to Mobile Generator Sets (commo- electronics)
TB 750-651	Antifreeze and Cooling Systems
TC 11-6	Grounding Techniques
TM 9-6140-200-14	Lead-Acid Batteries

Use these publications along with the generator TM's and LO's of the specific generator sets in your unit. Don't forget the pubs that support the Mil Std engines on the generators.

You can also get some good information from TEC Lessons. You'll find a list of these in Extension Training Material Status List. Your Training NCO can steer you to this publication, as well as others listed in "A Formula for Success," Page 1.

COMMO

On
Your New
AN/UGC-
74A (V) 3...

Stop Terminal Illness


MAKING LIFE MORE COMFORTABLE
FOR YOUR NEW COMMUNICATIONS TERMINAL
(AND YOURSELF, OF COURSE) MEANS
DOING THE LITTLE THINGS.

Be a Smooth Operator

Sure, your terminal is rugged. But a little TLC and common sense can help.

Take it easy on the keyboard. Those plastic keys will snap off if


Keyboard takes
light touch



hooked by a sleeve or mashed too hard.

At the other end, watch cable connections and insulation when sliding the terminal from the rear case.

Watch cables
when sliding case



Those plugs need special—and careful—handling, anyway. They are not soldered and will break easily if roughly handled. Plug and unplug with care.

Cut the Power

Turn power OFF when you're making or changing switch settings. Same goes for plugging or unplugging the print control or print drum motor speed plugs. The driver card module can blow if you have power ON.


Watch the switch when you're ready to close the dust cover, too. The power switch should be in the same position as the switch lever. If it's not, when you latch the cover, the switch can break.

YOU KNOW IT,
SPARKS!

OPERATORS AND REPAIR-TYPES
DOING THE LITTLE THINGS CAN MAKE
A BIG DIFFERENCE IN KEEPING
EVERYONE ON-LINE AND
OPERATING!



Be sure power
lever is in the
same position as
switch before
closing cover




So, when you replace the cover, hold the switch in the position—ON or OFF—that terminal is operating in.

Cards firmly seated?



Be sure all cards and plugs are firmly seated. If they're not, it won't make any difference what position the power switch is in. Something won't operate when you expect it to.



Make the Switch

Making the right switch settings is job one with the -74. And, settings must be the same on all terminals operating in a radio net.

For instance, if you're going to use a 60-WPM setting, the Baud rate switch should be on 45.5. When the LINE lamp is on, it could mean someone in the net is in the wrong position.

Another setting to watch is line length. If you're using ICT state, and in a net with a radio teletypewriter set still using the old TT-98 teletypewriter, set your line length at 69 with the line subcommand.

A button to keep an eye on (and a heavy finger off) is PARITY RESET. That's the button you hit during a self-test of your set.

The spring-loaded button is meant to pop back each time you hit it. Hitting it too hard, tho, or holding it too long, can make it stick. You can't unstick it. Your org repair shop will have to replace it before the terminal will operate again.

A final operational tip: Your new machine is built to warn you if a high priority message has been received. You have to give it a hand, tho, by modifying message format a little.

The -74's alarm is activated when the message precedence is the first character of the second line. So, if you're sending an "O" or "OP" message, you should rearrange the format to put precedence there.

IF THE
CODE IS
ANYWHERE
ELSE, THE
WARNING
LIGHT WON'T
LIGHT AND
THE ALARM
WON'T
SOUND!

Paper, Ribbon

Changing the ribbon on your machine is a delicate task.

If your ribbon is short a leader, make one for it. Take a length of adhesive tape and cut it in half lengthwise. Wrap it around the bottom spool several times and then attach it to the tape. Now wind the new leader onto the takeup reel.

Adding paper has taken a new shape, too. C1 to TM 11-5815-602-12 says to put the point to one side, instead of in the middle. Makes it easier to thread through the machine.



Once you have the paper showing out the front, you can release the pressure lever and pull the paper up.

Add paper when you need it. Keep an eye on the PAPER LOW light. If you wait, or think you can get by with your old roll, you risk running out. That locks up your machine and stops traffic.

Finally, remember any time you work with the dust cover down—to change paper or a ribbon, for example—watch rings and jewelry. You can short out a circuit easily with a touch on exposed connections.

Now, a Word for Repairmen

The word is light, as in touch.

When making adjustments, too much muscle is trouble. Like when you make the ribbon slip clutch adjustment. Overtightening will mash the spring. Then the ribbon won't turn.

Hook the spring gage in the top ribbon spool. With the motor running, let the spool pull the gage. When you get between 10 and 12 ounces of tension, the spool will stop. If yours doesn't, the slip clutch needs adjustment.



Then, when you tighten the ribbon sensing lever, give it no more than 3 or 4 ounces of tension.

A light touch is also needed when you're through setting the timing. Overtightening the mounting screw can break the microprocessor's plastic case.

Finally, when you're sliding the ribbon mechanism back into place, never set the drive gear too tightly against the intermediate gear it meshes with. The metal gear can grind down and damage the plastic one.

You'll hear a whining noise during operation if the two are too tightly meshed.

Make TD-660 a Winner...

Practice Panel PM

GOOD BOARD-WORK IS YOUR KEY TO KEEPING STRONG SIGNALS COMING THRU YOUR MULTIPLEXER!


EVERYTHING'S OK AT THIS END! BONNIE AND I CHECKED IT OUT!



It starts with proper handling of the pluck-out panels that carry the printed circuit boards.


First things first, tho. Be sure you're using the right boards. A mix of old (11A2 through 11A8) and new (11A23 through 11A29) circuit boards creates static on the -660's channels.

Use same with same. That means all old or all new style. No mixing.



Any time you install a board, be sure the -660 is OFF. Plugging into a switched-on set can blow your new card's printed circuits.

Easy does it when pushing or pulling a board too. Those pins are fragile. Rough handling can bend or break 'em.




Always push and pull straight. Use the board's square key to guide your actions.

If you do bend a pin, don't turn in the board yet. First, try to straighten the pin with needlenose pliers.

So, cards are straight and snug. You've tested 'em to verify contact. Be sure to reset the channel selector and talk-monitor switches to OFF. If you don't, you cut the power level in half. That could lead you to turn in your set for repair when it's really OK.


Finally, be sure to replace the set's card cell cover. Without it, cards can

jiggle loose. Then you've got bad contact or none at all. It can also let in dirt and dust to short you out.



Kit Replacements

OH... I'M GONNA PACK UP MY TROUBLES IN MY OL' KIT BAG...



Order the parts, not the whole kit, when you need replacements for MK-1823 or MK-1885 kits. The complete kits are initial issue only items.

The MK-1823 maintenance kit for an SB-3614 switchboard is broken out only in TM 11-5805-695-34P, tho. Get with your support for the NSN's.

Parts for the AN/TTC-41 telephone central's MK-1885 installation kit are in a new Chap 5 to TM 11-5805-693-12. C1 added the info.

GAAAA--
A
LEOPARD
??

NAAAH!
EVEN WITHOUT
GOGGLES I CAN
SEE IT'S ONLY
TABBY!

Night Sights Spotted?

SOMEBODY OUGHTA CLUE
HIM IN ON GOOD NIGHT
VISION GOGGLE CARE!

A spotted pair of AN/PVS-5 night vision goggles spells trouble for you, operator.


Before Your Eyes

You "spot" the image intensifier tube by leaving off the lens caps when your goggles are idle. Sunlight, or strong artificial light, can burn large dark spots in your field of vision. That spells big trouble when you put the goggles to use.

If you see big spots, turn in your goggles for repair. Small pin-hole-size dots are no problem, tho.

Head off spots by always using the lens caps when you're through with the gear, and during daylight hours.

Use lens
caps to
protect
goggles



Before the Enemy's Eyes

Another "spotting problem" is leaving on your IR illuminator during normal use. The infrared light will give away your position to any enemy observer in the area.

Protect yourself by using the IR only for close-in work, like map reading, when natural light is bad. When you're through, replace the lens caps real fast.

HEY,
SOLDIER...

O-Ring Assortment

...YOU CAN ORDER
300 OF US NOW...

YEAH--
YOU GET
A SIZING
GAGE,
TOO!

An assortment of 300 O-rings is now available under NSN 5330-00-966-8657. Sizes range from 1/8-in to 1 3/4-in inner diameter. The kit comes with a sizing gage so you can determine which O-ring to use.

Connie's Mini Minis

HA-HA!

HO-HO!

CONNIE... YOU GOT A
MAINTENANCE PROBLEM!

Connie Rodd
PS Magazine
Lexington, KY
40511

Metal Gage OK for 1/4-Ton

If you need to readjust the Prestolite distributor in your M151-series truck, you can use the metal feeler gage in the No. 1 Common tool kit. It'll work OK in adjusting the sensor—Para 5-6, Step 11, TM 9-2320-218-20-1-1. Or, save the plastic gage that comes with the distributor.

New Cooling System TB

Make sure you're up to date on use of antifreeze solutions and cleaning compounds in engine cooling systems. The latest TB 750-651 is dated 20 Jan 83. It's got some important info that wasn't in the old TB.

Tank-Mounted Dozer TM

All you drivers and mechanics with M9 bulldozers mounted on your tanks need the revised TM 9-2590-209-14&P. It's the first major revision of the TM since 1963. The TM contains a complete PMCS and a new lube chart.

Filter Washing's OK Again

Air cleaner filter elements on M48A5- and M60-series tanks can now be washed. For about 18 months, filter element washing was a no-no. Check out your tank's -20 TM or TB 9-2300-378-14 for washing instructions. Cleaning with compressed air is also still OK.

NATO SP Cable

NSN 5935-00-258-9156 gets a replacement terminal for the NATO special purpose cable kit that's part of your No. 1 Common shop set. NSN 5935-00-322-8959 gets a 3-part, 2-prong adapter for the NATO cable that lets you slave start vehicles with 2-prong receptacles.

Clean Air for Tanks

It's here—the latest info on how to keep your tank's air cleaner system in top shape! Check out TB 9-2300-378-14, Air Induction System Maintenance for M48- and M60-series tanks.

M872 Trailer Hazard

Temporary operating restrictions are in effect for all M872 34-ton semitrailers made by the Southwest Truck and Body Company. Some M872's have developed frame cracks forward of the front axle.

The restrictions deadline vehicles with known frame cracks and limit all others to a maximum of 17 tons. No ammo or armored personnel carriers are to be hauled on the trailers.

Restrictions will apply until individual trailers, including those without frame cracks, are repaired or strengthened.

Details are in TACOM Messages DRSTA-MVA 011530Z and 081530Z Oct 82. Look for other messages with more word on the problem.

* U.S. GOVERNMENT PRINTING OFFICE: 1983—659-007/3

Would You Stake Your Life *right now* on the Condition of Your Equipment?

PACK

PM

WITH
EVERY ITEM
YOU SEND
FOR REPAIR

1 Use original
boxes or
"Fast Pack"

2 Pack **all**
parts!

3 Use
padding!

4 Pack it
snugly!

5 Tag NSN,
item and
destination!

6 Inclose
records!
(if required)